

# TEALtainer

This TEALtainer fresh and waste water container is for use with the WashStand Xtra portable hand wash unit.

## User information

1. Position your WashStand Xtra so that you can gain access to the TEALtainer on the left side of the unit.
2. The waste water is contained within a heavy duty polyethylene bag - when the fresh water is used up, the waste bag will be full.
3. Pull both the fresh water and waste water hoses and remove the TEALtainer from the unit.
4. Drain the TEALtainer completely and dispose of all water to a sluice or foul water drain.
5. Flush out the waste compartment (red cap) with fresh water. Make sure that the waste bag is empty.
6. Fill the fresh water bag (white cap) from the cold tap to just below the filler cap.
7. Return the TEALtainer to the side of the WashStand Xtra and push in the fresh water delivery pipe, **making sure that the waste pipe is inserted into the red waste cap hole.**
8. The unit can now be positioned for use.

**Do not** re-use waste water.

For cleaning, maintenance and operator instructions, please refer to the user instructions on the back of the WashStand Xtra.

All Teal mobile hand wash unit information and maintenance documentation can be obtained from the user manuals page of the Teal website:-

<https://www.tealwash.com/user-manuals/>



**Teal support Monday-Friday 8-5 (Fri 1pm)  
Helpline 0121 770 0593**

Teal Patents Ltd, Unit 2 Waterloo Avenue  
Chelmsley Wood Industrial Estate  
Birmingham B37 6QQ  
Tel: +44(0) 121 770 0593  
Email: [enquiries@tealwash.com](mailto:enquiries@tealwash.com)  
[www.tealwash.com](http://www.tealwash.com)