The KiddiWash Xtra
Installation and operating instructions

The KiddiWash Xtra
Installation and operating instructions

Index

IMPORTANT SAFETY INSTRUCTIONS

Caution Hot water

Not drinking water

This sink for hand wash only

Before using this appliance, read all instructions and familiarise yourself with the operation of the unit

1. The KiddiWash Xtra can be used by children of all ages. It is however, important that children are taught how to use it properly.

2. Supervise children when washing to make sure that they wash their hands effectively.

3. Cleaning and user maintenance should not be made by children without supervision.

4. The unit should only be used in accordance with these instructions. Do not carry out any maintenance other than is shown in these instructions or as advised by Teal Patents service support.

5. Do not place in a hot area of more than 70˚C.

6. Water dispensed is not suitable for drinking.

7. Unit must only be used on a flat, even surface. It must be used only in an upright position. An adult should position the unit and fill it with clean water before allowing a child to use the unit.

8. Unit may be wall mounted: if so, use the provided fittings for a solid brick wall. If mounting on an alternative type of wall, ensure that you use appropriate fittings.

9. Unit should be positioned where it does not obstruct walkways or access to services.

10. Unit must only be filled with clean water of the required temperature, which should not exceed 40˚C.

11. Do not overfill: only fill to the water level indicated on the *parts identification* photograph on page 7.

12. If the appliance is not working as it should, has been dropped or damaged, do not use. Contact the seller or Teal Patents Ltd.

13. This equipment is for preheated water for handwashing only. It is not designed for washing of crockery or other items.

14. The unit cannot be operated without water.

15. Waste water is removed by taking out the bowl and tipping the water from the water drainage slot.

16. **This unit must not be subjected to a high pressure water jet.**

17. Any spillages should be cleaned-up as soon as possible to avoid slipping hazards.

18. Waste water should be disposed of to a foul drain.

19. Keep unit away from direct heat sources.

20. Do not alter the unit in any way this will invalidate the warranty and may make it unsafe to operate.

Box contents

Before installing the unit check that all parts are present and undamaged.

In the event of any shortages or damaged items contact the retailer.

Do not attempt to use substitute parts except as stated in these instructions.

Contents consist of:
- 1 KiddiWash Xtra unit
- Carrying strap fitted to the unit
- 1 fittings pack consisting of:
    - 4 rawlplugs and 4 mounting screws
    - 4 mounting spacers
- 1 drilling template.

Carrying handle

Lid

Water tank

Tap

Plug hole

Water drainage slot

Rear of bowl

Lid seal

Plug hole

Removable rubber cover

Water level indicator

Upper mounting holes

Carrying handle

Lower mounting holes

Rear of KiddiWash Xtra

Disclaimer

Teal Patents Ltd has a policy of continual improvement in product quality and design.

The company reserves the right to change the specification of its models at any time.

Installation

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY INVALIDATE YOUR WARRANTY.

Wall Mounting Or Free Standing

This unit has been designed for wall mounting or to be placed on any firm, flat, level surface.

Before fixing to a wall, check that you have all the parts listed.

The rawlplugs provided are suitable for use in a solid brick wall. If mounting on an alternative type of wall, ensure that you use appropriate fittings.

Before commencing installation check that you have appropriate tools and a suitable workspace.

Failure to follow these instructions may result in personal injury, damage to the product or damage to property.

Check that there are no hidden service pipes or cables in the area where you intend to drill.

If you are unsure consult a suitable qualified installer.

Ensure that the position of the unit allows sufficient space for the opening of the lid and the safe opening of the bowl.

Using the supplied template identify the locations for the 4 mounting screws.

Drill holes using an 7mm diameter drill bit.

Fit rawlplugs in each hole.

Mount the unit using the 4 screws and mounting spacers provided.

Note: the bowl must be removed to provide access to the two lower mounting holes. Lift the lid to access the upper mounting holes.

Do not overtighten fixings as this may damage the unit.

Take care not to drop tools or fixings into the unit.

Check that the unit is upright and level before filling.

Waste Water

All KiddiWash Xtra models have a removable bowl that retains all the dirty water.

There is no need for a separate waste pipe or waste water storage container.

Operating instructions

Unit must only be filled with clean water of the required temperature, which should not exceed 40˚C.

Do not overfill - only fill to the water fill line indicated on the inside of the unit.

Close lid and ensure seal is fully engaged.

Use the tap to discharge water to wash hands.

If a continuous flow of water is required, fully depress the tap lever.

Waste water will drain into the hollow bowl.

To remove waste water, detach the bowl and lift it out.

Tip the water from the water drainage slot on the front edge of the bowl into a foul water drain and replace.

Rinse with clean water.

Refill the unit and with clean water of the required temperature, which should not exceed 40˚C.

Cleaning instructions

Empty the detachable bowl to a foul water drain and rinse with clean water.

If unit is left unused for an extended period it is recommended that it is emptied of water and replenished with fresh water.

Clean all surfaces with an anti-bacterial wipe or disinfectant paying particular attention to frequent contact points. To clean the inside of the bowl, first take off the removable rubber cover.

Do not use abrasive cleaners which may scratch the external surfaces.

This unit must not be subjected to a high pressure water jet.

The unit should be disinfected weekly using a hypochlorite solution such as Milton Sterilising Fluid at a concentration of **500ppm for 5 minutes** and then flushed through with fresh water.

Troubleshooting guide

No water dispensed. Check water level in tank

Water cold. Refill the unit with clean water of the required temperature, which should not exceed 40˚C.

Water around unit. Clean up any spillage from filling unit.

Check that the bowl is not full.

If further water is seen, stop using the unit and contact the supplier for advice.

Optional extras

Towel holder   ref GENTWLHDR

Soap bottle and bracket   ref GENSOAPDISP/BRKT

Guarantee

All Teal Patents products are tested before leaving the factory.

The unit is covered by a two year return to manufacturer warranty from date of purchase – please ensure that you retain proof of purchase.

Any faulty items will be repaired or replaced, and the repairs guaranteed for the remainder of the original warranty period.

Exclusions

Teal Patents will not be liable to repair or replace goods where:

- The fault has been caused through misuse, accidental damage, use contrary to the manufacturers instructions or damage in transit
- Repairs have been attempted by someone other than Teal Patents or an authorised dealer
- The appliance is second hand
- The warranty does not cover any claims for consequential loss or damage.

This guarantee does not affect your statutory rights as a consumer.

The KiddiWash Xtra

Product Specification:

Height	370mm
Width	310mm
Depth (bowl open)	370mm
Depth (bowl closed)	220mm
Weight	3Kg empty
	6.3Kg full
Water capacity	3.3 litres

Teal Patents Ltd

Unit 2, Chelmsley Wood Industrial Estate
Waterloo Avenue, Chelmsley Wood
Birmingham B37 6QQ, UK
Tel: +44 (0) 121 770 0593
www.tealwash.com
Email: enquiries@tealwash.com