

# TEALtainer

This TEALtainer fresh and waste water container is for use with the Super Stallette portable hand wash unit.

## User information

- 1. Warning** - switch off your Super Stallette before handling the TEALtainer.
2. Disconnect the water delivery pipe from the blue ringed connector and remove the TEALtainer.
3. Drain the TEALtainer completely and dispose of all water to a sluice or foul water drain.
4. Fill with cold water through the large opening up to the side indentation.
5. Return the TEALtainer to the Super Stallette and reconnect the fresh water delivery pipe, **making sure that the waste pipe is inserted into the red waste cap hole.**
6. Switch on the power. The unit will automatically run a 10 second cold water purge.
7. The Super Stallette is now ready for use.

**Do not** re-use waste water.

For cleaning, maintenance and operator instructions, please refer to the user instructions on the inside of the door of the Super Stallette.

All Teal mobile hand wash unit information and maintenance documentation can be obtained from the user manuals page of the Teal website:-

<https://www.tealwash.com/user-manuals/>



**Teal support Monday-Friday 8-5 (Fri 1pm)  
Helpline 0121 770 0593**

Teal Patents Ltd, Unit 2 Waterloo Avenue  
Chelmsley Wood Industrial Estate  
Birmingham B37 6QQ  
Tel: +44(0) 121 770 0593  
Email: [enquiries@tealwash.com](mailto:enquiries@tealwash.com)  
[www.tealwash.com](http://www.tealwash.com)