

The WashStand Xtra Installation and operating instructions



Manufactured by:

Teal Patents Limited

Unit 2

Chelmsley Wood Industrial Estate

Waterloo Avenue

Chelmsley Wood

Birmingham B37 6QQ

Telephone: 0121 770 0593

Email: enquiries@tealwash.com

www.tealwash.com





The WashStand Xtra Installation and operating instructions

Index

Important safety instructions	page 4
Box contents	page 5
Parts identification	page 6
Installation	page 8
Operating instructions	page 9
Cleaning instructions	page 10
Troubleshooting guide	page 10
Guarantee	page 11
Technical specification	page 12


Page 2 Page 3

IMPORTANT SAFETY INSTRUCTIONS









Before using this appliance, read all instructions and familiarise yourself with the operation of the unit

- 1. This appliance can be used by children aged from eight (8) years and above, persons with reduced physical, sensory or mental capabilities, or persons with lack of experience and knowledge only if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Cleaning and user maintenance shall not be made by children without supervision.
- Children should be supervised to ensure that they do not play with the appliance. This is not a toy.
- The unit should only be used in accordance with these instructions. Do not carry out any maintenance other than is shown in these instructions or as advised by Teal Patents service support.
- 4. Do not place in a hot area of more than 70°C.
- 5. If the appliance is not working as it should, has been dropped or damaged, do not use. Contact the seller or Teal Patents Ltd.
- 6. Water dispensed is not suitable for drinking.
- 7. Unit must only be used on a flat, even surface. It must be used only in an upright position.
- 8. The unit can safely be used both indoors and outdoors.
- 9. Unit should be positioned where it does not obstruct walkways or access to services.
- 10. Unit must only be filled with clean water of the required temperature, which should not exceed 40°C.
- 11. Do not overfill: only fill to just below the white fresh water filler cap base.
- 12. The unit will not operate without water.

- 13. Waste water is removed by taking out the white waste water bottle.
- 14. Waste water should be disposed of to a foul drain.
- 15. This unit must not be subjected to a high pressure water jet.
- 16. Any spillages should be cleaned up as soon as possible to avoid slipping hazards.
- 17. Keep unit away from direct heat sources.
- 18. Do not alter the unit in any way this will invalidate the warranty and may make it unsafe to operate.

Box contents

Before installing the unit check that all parts are present and undamaged.

In the event of any shortages or damaged items contact the retailer.

Do not attempt to use substitute parts except as stated in these instructions.


Contents consist of:

- 1 WashStand Xtra unit
- Paper towel holder
- Soap bottle
- Soap bottle holding bracket.

Page 4 Page 5

Parts identification





Clean water pipe (white cap)

Dirty water pipe (red cap)

TEALtainer water container

There are 2 wheels at the rear of the unit

TEALtainer water container carrying handle



TEALtainer water container instructions

Disclaimer

Teal Patents Ltd has a policy of continual improvement in product quality and design.

The company reserves the right to change the specification of its models at any time.

Page 6

Installation

FAILURE TO FOLLOW THESE INSTRUCTIONS MAY INVALIDATE YOUR WARRANTY.

Free Standing

This unit has been designed to be used only in an upright position on a firm, flat level surface.

The unit can safely be used both indoors and outdoors.

Position your WashStand Xtra so that you can gain access to the TEALtainer water container on the left side of the unit before filling or emptying.

Failure to follow these instructions may result in personal injury, damage to the product or damage to property.

Do not overtighten fixings as this may damage the unit.

Check that the unit is upright and level before filling with clean fresh water.

Waste Water

All WashStand Xtra models come complete with a TEALtainer water container: the waste water is contained within a heavy duty polyethylene bag - when the fresh water is used up, the waste bag will be full.

There is no need for a separate waste pipe or waste water storage container.

Do not re-use waste water.

Operating instructions

Withdraw both the clean water hose (white cap) and the dirty water hose (red cap) and remove the TEALtainer from the unit. The TEALtainer has a carrying handle for easy transportion to a water supply.

Make sure that the waste bag is empty.

Fill the fresh water bag (white cap) with clean water of the required temperature (which should not exceed 40° C) to just below the filler cap.

Return the TEALtainer to the side of the WashStand Xtra and push in the fresh water delivery pipe, making sure that the waste pipe is inserted into the red waste cap hole.

The unit can now be positioned for use on a flat, level surface.

Use the foot pump to discharge water to wet hands.

Apply soap and wash hands thoroughly for at least 20 seconds.

Use the foot pump to discharge water to rinse hands.

Waste water will drain into the waste water container bag in the TEALtainer water container.

To remove waste water, remove the water container and lift it out.

Tip the water from the TEALtainer water container into a foul water drain.

Rinse with clean water.

Refill the unit and with clean water of the required temperature, which should not exceed 40°C.

Cleaning instructions

Remove both the clean and dirty water hoses and remove the TEALtainer from the unit.

Drain the TEALtainer completely and dispose of all water to a sluice or foul water drain.

Flush out the waste compartment (red cap) with fresh water. Make sure that the waste bag is empty.

If unit is left unused for an extended period it is recommended that it is emptied of water and replenished with fresh water.

Clean all surfaces with an anti-bacterial wipe or disinfectant, paying particular attention to frequent contact points. Do not use abrasive cleaners which may scratch the external surfaces.

This unit must not be subjected to a high pressure water jet.

The unit should be disinfected weekly using a hypochlorite solution such as Milton Sterilising Fluid at a concentration of **500ppm for 5 minutes** and then flushed through with fresh water.

Troubleshooting guide

No water dispensed. Check water level in tank.

Water cold. Refill the unit with clean water of the required temperature, which should not exceed 40°C.

Water around unit. Clean up any spillage from filling unit.

Check that the waste water container is not full.

If further water is seen, stop using the unit and contact the supplier for advice.

Guarantee

All Teal Patents products are tested before leaving the factory.

The unit is covered by a two year return to manufacturer warranty from date of purchase – please ensure that you retain proof of purchase.

Any faulty items will be repaired or replaced, and the repairs guaranteed for the remainder of the original warranty period.

Exclusions

Teal Patents will not be liable to repair or replace goods where:

- The fault has been caused through misuse, accidental damage, use contrary to the manufacturers instructions or damage in transit
- Repairs have been attempted by someone other than Teal Patents or an authorised dealer
- The appliance is second hand
- The warranty does not cover any claims for consequential loss or damage.

This guarantee does not affect your statutory rights as a consumer.

Page 10 Page 11

The WashStand Xtra



Technical specification

Product Specification:

Weight (unboxed) 14kg Height (front) 895mm

Overall height

(including Handle) 1120mm Width 440mm Depth 645mm Washes per fill 50



Teal Patents Ltd

Unit 2, Chelmsley Wood Industrial Estate Waterloo Avenue, Chelmsley Wood Birmingham B37 6QQ, UK Tel: +44 (0) 121 770 0593

www.tealwash.com

Email: enquiries@tealwash.com