

TEALtainer

This TEALtainer fresh and waste water container is for use with the Hygienius portable hand wash unit.

User information

1. **Warning** - switch off your Hygienius before handling the TEALtainer.
2. The waste water is contained within a heavy duty polyethylene bag - when the fresh water is used up, the waste bag will be full.
3. Disconnect the TEALtainer from the fresh water pick up pipe (white cap) and remove from unit.
4. Drain the TEALtainer completely and dispose of all water to a sluice or foul water drain.
5. Flush out the waste compartment (red cap) with fresh water. Make sure that the waste bag is empty.
6. Unscrew the white cap and fill the fresh water bag from the cold tap to just below the filler cap. Refit the white cap.
7. Return the TEALtainer to the Hygienius and reconnect the fresh water delivery pipe, **making sure that the waste pipe is inserted into the red waste cap hole.**
8. Switch on the power. The unit will automatically run a 10 second cold water purge.

Do not re-use waste water.

For cleaning, maintenance and operator instructions, please refer to the user instructions that are supplied with the Hygienius.

All Teal mobile hand wash unit information and maintenance documentation can be obtained from the user manuals page of the Teal website:-

<https://www.tealwash.com/user-manuals/>



**Teal support Monday-Friday 8-5 (Fri 1pm)
Helpline 0121 770 0593**

Teal Patents Ltd, Unit 2 Waterloo Avenue
Chelmsley Wood Industrial Estate
Birmingham B37 6QQ
Tel: +44(0) 121 770 0593
Email: enquiries@tealwash.com
www.tealwash.com