

Teal 12/24 volt vehicle unit cleaning instructions

Routine cleaning of Teal vehicle units

It is recommended that the Teal Handeman Xtra, Compact Classic, Compact Welfare, Handeman Original and TealWash products should be drained and replenished with fresh water daily.

The units should be disinfected weekly using a hypochlorite solution such as Milton Sterilising Fluid at a concentration of 500ppm for 5 minutes and then flushed through with fresh water.

The tap nozzle can be removed for cleaning if required.

External surfaces should be wiped over with a soft non-abrasive cloth using a Milton solution.



Handeman Xtra

(HMX, 12 or 24v)
12v/220w : 24v/250w



TealWash

(TW, 12 or 24v)
12v/220w : 24v/250w



Compact Classic

(CC, 12 or 24v)
12v/180w : 24v/250w



Handeman Original

(HMO, 12 or 24v)
12v/220w : 24v/250w



Compact Welfare

(CW, 12 or 24v)
12v/180w : 24v/250w



TEAL Patents Ltd

Unit 2, Waterloo Avenue
Chelmsley Wood Industrial Estate
Chelmsley Wood
Birmingham, B37 6QQ, UK
Tel: +44 (0) 121 770 0593
Email: enquiries@tealwash.com

Order online at www.tealwash.com